

STANDARD TIMBER FRAME DETAILS

The enclosed details are indicative of current practise of Firwood Timber Frame and are used as guidance only.

Any timber frame structure manufactured and supplied by Firwood Timber Frame will be designed specifically for the project and will be detailed accordingly.

Construction of the timber frame must be carried out in accordance with drawings and details for construction.

All details must be read in conjunction with all relevant Architects and engineers' details.

We reserve the right to amend details to suit changes in building regulations and building practices.

Contents page

- Nailing
- Soleplate
- Fixing: external by shot firing
- Fixing: external with soleplate anchors
- Fixing: external soleplates with restraint straps
- Fixing: internal soleplates

- Flooring
 Joist fixing
 Chipboard decking fixing
- External wall first floor junction
- Floating floor
- Floating floor: installation details
- Floating floor: internal door threshold detail Floating floor: flat entrance door threshold detail
- Panel erection Panel fixing
- Breather paper
- Cavity barrier
- Cavity barrier: Compartment floors
- Party walls
- · Party wall: steps
- Party wall: Staggers
- Compartment walls: roof space
- Roof setting out
- Standard eaves
- Standard verge
- Parapet verge
- Parapet eaves

- Chimneys Internal chimney
- External chimney
- Intermediate chimney
- Services
- Party wall electrics
- Balanced flue
- Concrete flue Soil & vent pipe detail
- Notching and holes in joists
- Additional information Vertical shrinkage

Scaffolding requirements

Timber Frame

Nailing Schedule

Soleplates

32x3.75mm dia rustproofed square twisted Hilti NK 27 or 72 S12 or similar

External & Internal panels

50x3.0mm dia rustproofed plain head 75x3.35mm dia rustproofed plain head

90x4mm dia rustproofed plain head

Walls/miscellaneous

75x3.35mm dia rustproofed plain head 40x2.65mm dia stainless steel ringed shank Galvanized staples Stainless steel staples

Floors

90x4mm dia rustproofed plain head

75x3.35mm dia rustproofed plain head 32x3.75mm dia rustproofed square twist 60x3.35mm dia rustproofed ringed shank

2 per soleplate anchor 600c/s or greater, soleplate & soleplate anchors

Sheathing to panel
Bottom rail of panel to soleplate @ 300c/s and staggered
All panel to panel junctions @ 600c/s
Plasterboard noggins
38x89 noggins to ceilings at head of parallel partitions
Tee junction skew nail @ 600c/s

Timber firestop battens to timber frame
Loose brick ties to external panels
Polythene vapour barrier to external panels
60x65 mineral wool cavity barrier to external panels
Joist to header

Stitching headers and joists to panels
Solid strutting to joists
Herring bone strutting to joists
Joists and trimmers to hangers
Decking to joists in accordance with manufactures recommendations Generally @ 150mm c/s

Nailing Schedule

Roof

65x3.35mm dia rustproofed plain head

75x3.35mm dia rustproofed plain head

90x4mm dia rustproofed plain head

65x3.35mm dia rustproofed lost head 40x2.36mm dia rustproofed lost head 32x3.75mm dia rustproofed square twisted


40x3.35mm dia rustproofed clout nails

External joinery

32x3.75mm dia rustproofed square twisted

Vent to fascia
Tiling battens and counter battens to rafters
Tilt ply to rafters
Wind bracing to trusses and peak panels
Plasterboard noggins
Eaves framing to rafters, external panels etc.
Spandrel panels to external panels below
38x89 ceiling batten to spandrel panel
Blockings to base of spandrel panel to take wind bracing
Ditto to flank walls
Verge sprocket to trussed rafters
Verge sprocket to verge rafter
Tank stand material
Fascias, bargeboards and any other exposed items
Soffit ply to bearers/sprockets
Truss clips to trusses and wallplates
Truss hangers to trusses
Sarking felt to rafters

Frame cramps to windows/doors and external panels



1. Masonry Walls 2.D P C

3.Bottom of Panel shot fired into Slab

4. Breather Paper 5.9.5mm Sheathing Plywood 6. Insulation

8. Plasterboard 7. Wall Ties

9. Vapour barrier in 500g polythene with 100mm laps or vapour control plasterboard

External Soleplate fixing


- Anchor plate to concrete floor using Hilti nails shot fired at centres as shown on soleplate layout
- DPM is to be adequately lapped with

2

- W Soleplates must be level, square & levelling must not exceed 20 mm straight. Any mortar bed used for
- cide with joints in panels Butt joints in soleplate should not coin-

4

Standard details Timber Frame



1. Masonry Walls 2.D P C 3. Soleplate Anchors

4. Breather Paper
5.9.5mm Sheathing Plywood
6. Insulation

9.Plasterboard 10.Vapour barrier in 500g polythene with 100mm laps or vapour control plasterboard

External Soleplate fixing

- Anchor plate to concrete floor using soleplate anchors, fixed as per nailing schedule
- DPM is to be adequately lapped with DPC

12

Soleplates must be level, square & straight. Any mortar bed used for levelling must not exceed 20 mm


Ņ.

Butt joints in soleplate should not coincide with joints in panels

4

Soleplate anchors nailed @ 800c/s unless stated & each side of openings

5



1. Masonry Walls
2.D P C
3. Restraint strap
4. Breather Paper
5.9.5mm Sheathing Plywood
6. Insulation
7. Wall Ties
8. Soleplate
9. Plasterboard(supplied by others)
10. Vapour barrier in 500g
polythene with 100mm laps or
vapour control plasterboard

Restraint strap fixing

- Anchor plate to concrete floor using Hilti nails shot fired at centres as shown on soleplate layout
- DPM is to be adequately lapped with DPC

'n

Soleplates must be level, square & straight. Any mortar bed used for levelling must not exceed 20 mm


W

Butt joints in soleplate should not coincide with joints in panels

4.

Restraint strap Must be screwed to masonry & timber frames, nailing is not acceptable To be spaced no more than 2m c/s

5



1.Panel
2.D P C
3.Slab
4.Insulation
5.Soleplate provided as a
Screed Rail
6.Screed(if Applicable)
7.Plasterboard

Internal Soleplate fixing

- To be fixed as external panels
- Soleplates must be level, square & straight. Any mortar bed used for levelling must not exceed 20 mm Butt joints in soleplate should not
- Butt joints in soleplate should not coincide with joints in panels


ω

Soleplate anchors nailed @ 800c/s unless stated & each side of openings

4

- 1.Soleplate or topplate 2.Rimboard 3.Hanger

- 4. Traditional joist 5. Block under load bearing walls



General notes

- Actual joist positions and sizes to be in provided accordance with joist layout drawings
- 5 LPI joists are to be flush with panels flush with O.S.B of panels, Rimboard on Rimboard on standard joists are to be
- underneath parallel with joists noggins are required Where non-loadbearing partitions run


μ

LPI joist's do not require strutting 4.5m then two runs of solid strutting will One run of solid strutting is required if the joist span exceeds 2.4m, if it exceeds

4.

Timber Frame

Chipboard decking fixing



General notes

- Actual joist positions and sizes to be in accordance with joist layout drawings provided
- Flooring to edge of rimboard

?


All T & G edges to be glued using water resistant PVA

Ψ

- Maximum nalling around perimeter is
 300mm c/s
- Maximum nailing along joists is 400mm
- Nails to be punched 2mm below surface of decking

6

External wall first floor junction



- 7. Wall Ties
- 10. Fire Stop
- 1.Masonry Walls
 2.Topplate
 3.Joist
 4.Breather Paper to overlap rimboard
 5.9.5mm Sheathing Plywood
 6.Insulation
- 8.Rimboard 9.22mm Flooring
- 12. Blocking

General notes

- Actual joist positions and sizes to be in provided accordance with joist layout drawings
- Breather paper is to overlap rimboard

2

LPI joists are to be flush with panels Rimboard on standard joists are to be flush with O.S.B of panels, Rimboard on

ω

DPC is to be used to cover fire stop

4.

nal wall, then the joist must be situated If a joist is running parallel with the exterallow plasterboard to be fixed half on the wall & half of the wall to

5


panels are used (between each joist) Blocking is only required when 140mm

6.

Timber Frame

Floating Floor

1.Joist's
2.22mm chipboard
3.25mm fibreglass slab
4.19mm plasterboard plank
5.22mm chipboard
6.3mm space between skirting
& floor with resilient seal



General notes

- A 10mm expansion gap is to be left around perimeter walls and abutments
- All T & G edges to be glued using water resistant PVA

2

Chipboard to be bonded to 19mm plasterboard plank with 9mm dabs at 300 c/s of gyproc sealant

Ψ

Joints between chipboard and plasterboard to be staggered, and board directions reversed

25mm fibreglass rigid floor slab density

4

25mm fibreglass rigid floor slab density
75kg/m3 turned up at edges against walls

5

25mm upstand 480±1200 sheets down this face 480±1068 ______starter sheet 32mm 'off cuts' from cut sheats be used to form 25mm upstand's round panels & partitions Floating Floor installation 600x1068 sheets down this face 25mm Rigid slab installation Full sheets from this point details 1500x300 starter sheets 2400x300 sheets vays ensure that slab, plasterboard .nks & chipboard ar started from same corner of area to be covered. 1500x8p0 starter sheets Full sheets from this point 2400x300 sheets Full sheets 22mm Chipboard All T&G edges to be glued using water resistant PVA 1200x600 starter sheets


19mm Plasterboard plank installation

Standard details

Timber Frame

Floating Floor

1. Joist's
2.22mm chipboard
3.25mm fibreglass slab
4.19mm plasterboard plank
5.22mm chipboard
6.10mm expansion gap




Internal door threshold detail

- 10mm expansion gap provided within the 22mm t & g chipboard decking, located under internal door
- Expansion gap can be filled with appropriate compressible material if required, by others

2

Floating Floor

1. Header joist
2. Solid blocking between joists
3.50x300mm wide wire reinforced
mineral wool cavity barrier
4. plasterboard
5.10mm space between door
6.3mm space between skirting
& floor with resilient seal
7.38x140mm support for door frame
8.100mm fibreglass insulation
9. Plasterboard to local authority's requirements



flat entrance door threshold


- 10mm space between door frame and floor finish to have a resilient seal
- 38x140mm batten to provide support for door frame sill, skew nailed to joists

2

Flat entrance door to be fire resistant to local authority requirements

ω

Panel erection



General notes

- Set out panels in accordance with panel layout supplied with working drawings
- External panels the sheathing is on the external side

2

Check working drawings when positioning Internal panels which have ply to see what side to position the ply

w.


Ensure that panels forming walls are straight and plumb before fixing in permanent position

4.

Fix temporary wall braces to each butt joint and at a maximum 4m ctrs, during the erection sequence

5

Panel erection



General notes

- When panels meet at butt joints, corner joints or tee joints ,nail vertically at 300c/s
- Nails to be staggered 30mm on butt joints from edge of frame

2

Nails to be staggered 20mm on corner joints and tee joints from edge of frame


ÿ

4

- When internal panels run parallel with joists or trusses, noggins are required to be nailed at 90 deg to bottom of joists or trusses and to top of panel. 2 nails are required into top of panel
- Noggins are to be spaced at 600c/s

5

Breather paper



General notes

Fix breather paper in horizontal layers Vertical joints must have a minimum lap with a minimum of 100mm laps over lower layers to ensure run-off

2

of 150mm

- Vertical joints should be staggered
- ω wherever possible


4.

Breather paper may not be used as a DPC

of 25mm below the lowest timber mem-Breather paper must continue a minimum

'n

Timber Frame



Dwelling houses

- Cavity barrier at verge and eaves. Link eaves and verge cavity barriers
- Fire stopping required at junction of wall and external wall and roof

 40x47 sw batten around windows, doors

'n

and extract fans etc

2

Cavity barrier at party walls as shown on section


4


It is essential that the continuity of cavity barriers is maintained at eaves level

5

50x300mm wide wire reinforced mineral wool cavity fire stop between timber frame walls

6





Except Dwelling houses

- Cavity barrier at verge and eaves. Link eaves and verge cavity barriers
- Fire stopping required at junction of wall, external wall and roof

 40x47 sw batten around windows doors

2

40x47 sw batten around windows, doors and extract fans etc

μ

Cavity barrier at compartment walls and floors

4

It is essential that the continuity of cavity barriers is maintained at eaves level

'n


50x300mm wide wire reinforced mineral wool cavity fire stop between timber frame walls


6.


tandard details

Party walls










VERTICAL SECTION THROUGH PARTY WALL

AND COMPARTMENT FLOOR

Party walls

Where timber joists are at right angles to the party wall, full joist-depths blocking should be installed between each joist on the line of the edge of the lining to the wall to the block air paths. The blocking should be nailed to the wall plates above and below. The outer joists should be blocked tightly to the perimeter walls.

Party walls



20.

Header joist.

90mm thermal insulation in one leaf of party wall.
Skirting.

VERTICAL SECTION THROUGH STEPPED PARTY WALL

Steps and staggers

01. 12.5mm plasterboard on 19mm
plant with staggered joints

02. Plain vertical tiling on 38x25mm
tiling battens on 47x40mm counter
battens.

03. Supalux sheathing finished with
breather paper.

04. Lead flashing dressed up behind
tiling battens

05. 25x100mm ceiling tie bracing.

06. 60x40mm packer.

07. 90x40mm batten.

08. Roof insulation.

09. 12.5mm ceiling plasterboard.

10. 38x89mm support batten.

11. Party wall roof const. as details.

12. 19mm plank and 12.5mm plasterboard
layers to extent of staggered timber
frame.

13. 50mm thick wire reinforced mineral
wool cavity barrier to extend across
the full change of levels at 1st floor
and ceiling heights.

14. Standard flooring finish.
15. 19mm plank and 12.5mm plasterboard.
16. Double spaced joists.

17. Solid blocking between joists.

18. Header joist.

19. 90mm thermal insulation in one






Diagram showing positions of Cavity barriers and Fire Stops

Steps and staggers

Wall area between roofs to have half hour fire resistance externally and to be finished with light weight cladding

Party walls





tram showing positions of

- Staggers
 OH. 19mm plank and 12.5mm plasterboard layers.
 OE 90mm thermal insulation to one leaf of party wall only.
 OS 502500mm wide wire reinforced mineral wool cavity darrier.
 OH 90mm thermal insulation in external wall timber studwork.
 OF Plasterboard and vapour barrier.
 OF External wall mineral wool cavity barrier.
 OF External wall mineral wool cavity barrier.
 OF Stomm wide band of site-fixed breather

PLAN SECTION THROUGH STACCERED PARTY WALL

- paper.

 OB. Triber frame brick wall ties.


 O9. Sheathing layer and breather paper membrane.


 10. 300mm wide band of site-fixed breather.

staggers

Wall area between roofs to have half finished with light weight cladding hour fire resistance externally and to be

Standard details Timber Frame





COMPARTMENT WALL THROUGH ROOF SPACE

- LEGEND

 Of. Ridge fire-stopping with flexible mat on mineral wool insulation, to comply with B.S. 3958.


- 02. Continuous roof tile edge bedding.
 03. Roof sarking felt.
 04. Universal angle ridge tile.
 05. Concrete interdocking tiles.
 06. 25x38mm tilting battens.
 07. Trussed rafters.
 08. 38x47mm stud wall covered with 2 layers 12.5mm plasterboard, to both sides, laid with staggered joints before panels are tiffed into position and before roof trusses are erected. Roof insulation

70.

- 10. Compartment wall frame constructed from Holman vacuum-treated 38x47mm timber studs at 600mm c/c.
 11. 12.5mm ceiling plasterboard.
 12. Nog out the cavity at 1200mm c/c max to provide required support for the compartment stud wall frame.
- reinforced mineral wool cavity barrier.
 16. 3x40x240mm galv m.s. straps at party wall/ext. wall junctions, fixed with 40x2.65mm galv nails.
 17. 38x89mm timber studwork wall panels, with 90mm thermal insulation flaxible strips hand pressed between studwork. Insulation only required in one leaf of compartment wall. 13. 19mm plasterboard plank. 14. 12.5mm plasterboard. 15. 50mm thick x 300mm wide wire

Standard details Timber Frame

Roof



etting out

- Put Noggins between studs to be able to fix longitudinal bracing
- This setting out is only for standard truss types, if attic trusses or raised tie trusses are to be used then the truss is to positioned 50mm away from the gable end


5

See Truss layout provided with working drawings for setting out of trusses, metalwork and loose infill

w.

Standard details

Eaves



General notes

- This detail will vary depending on the pitch of the roof, the projection required and the soffit level, which in turn is often related to the window head level.
- 2. The relevant points to consider are:

 *Ventilation to roof space via soffit or
 proprietary over-eaves vents

 *Adequate tilting to eaves tile to maintain
 the tile line

 *The underlay extends into the gutter


 *Any cavity between the cladding and the
 timber frame wall is closed at the top by
 an appropriate cavity barrier

 *Roof insulation does not inhibit roof
 ventilation

 *Adequate precautions are taken to pre-

vent differential settlement

Verge



General notes

- No soffit bearer is required due to the soffit being fixed directly to the under side of the gable ladder.
- Attic and raised tie trusses are to be positioned 50mm away from spandrel panel.

 The Timber size of the gable ladders is no

?


The Timber size of the gable ladders is not the same as rafter size of the truss.

Ψ

Insulation is only required in the spandrel panel if the roof is habitable.

4

Parapet Eaves & Verge



General notes

- Stone coping to architects specification.

 Must be stable & self supporting
- Shrinkage Gap


2


- Pressed metal capping on 19x260mm plywood cap
- Lead flashing or similar to architects specification
- Parapet timber frame panel with sheating site fixed
- 38x89mm bearer


6

 Solid blockings between trusses to support parapet frame









ω

Gap for timber movement

4

See point 3 above

'n

Standard details Timber Frame


Internal chimney

- 200mm minimum non combustible back to fireplace recess
- Plaster board lining continued behind chimney and fireplace

2

liner is less than 200mm

non combustible material around flue 40mm minimum if thickness of



External chimney

- Movement gap between timber and masonry to be filled with mineral wool

 Mineral wool fire stop between fire and
- chimney

ω


- 40mm minimum if thickness of non combustible material around flue liner is less than 200mm
- Timber lintel must be at least 300mm from inner face of flue recess


4.

50mm cavity maintained around chimney with cavity wall ties as required

5

Chimney





Plan of stack at upper floor level

Intermediate chimney

See working drawings for joist and truss trimming around the chimney area Build wall ties into chimney after

2

Mineral wool fire stop between fire and chimney


Ψ

stabilise

construction of the timber frame to

Services





Socket outlet

Party wall electrics

Wiring can be located in the floor, roof or wall voids in timber frame construction


2

Wherever possible avoid placing the

electrical fittings in separating party walls

- Any services penetrating into the party wall must be adequately fire stopped and sealed for acoustic and sound requirements
- No outlets should be fixed or installed back to back
- See party wall details for insulation requirements

Services



1. Mastic sealant
2. Wire reinforced mineral
wool cavity barrier
3.12.5mm layer of asbestolux,
or similar
4. batten for fixing of boiler
5. Breather paper cut short and
dressed over dpc
6. battens to form surround of boiler
7.12.5mm layer of asbestolux,
or similar


Balanced fluc

- Balanced flue size to suit heating appliance. Refer to manufacturer's details
- Balanced flue terminal to be protected if less than 2m above ground level

2

Refer to boiler manufacturer's installation details, which may have more onerous installation requirements

W




Concrete fluc

The flue is to be done after the completion of the timber frame

andard details

Services



to enclosure duct

-89mm wall below

S & V pipe

Fire collar

Plan of S & V pipe and floor joist's

Header joist


Soil and vent pipe

- Soil and vent pipe to be a minimum of 65mm away from joists
- 2 Maximum diameter of pipe is 160mm
- Refer to manufacturer's details for fixing
- hole for pipe cut out square for 100mm dia. Pipe) with the 9mm supalux plate (approx. 200mm Cut away plywood sub-deck and install

4.

Standard details Timber Frame

Services




Notching & Holes in Joists

- Notches may be at the top or bottom of the joist, but not both at the same end. If notches are limited to the area between 0.1 and 0.2 of the span, the maximum notch depth may be increased to 0.15 x joist depth
- See standard details if I-joist system is to be used.

5

Vertical shrinkage

Location of openings	Solid ground floor	Suspended timber ground floor	Eaves and verges
Cround floor	3mm	5mm	8mm
1st floor	9mm	11mm	14 mm
2nd floor	15mm	17mm	20mm
3rd floor	21mm	23mm	26 mm




General notes

- Differential vertical movement between the timber frame and masonry claddings will occur
- Unless provision is made at the underside of openings and at roof soffit levels, damage may result

2

Scaffolding requirements



Scaffolding

- Scaffolding to cover all sides except the front when starting job
- Scaffolding to be sorted before commencement on site

5

Scaffolding required on the front when up to first floor level

ω